

The logo for SLIDE features the word "SLIDE" in a bold, orange, sans-serif font. To the right of the text is a horizontal trail of orange particles that tapers to a point on the right side, suggesting a spray or motion.

Slide Products, Inc. • 430 Wheeling Rd. • Wheeling, IL 60090 • P: 800-323-6433 • P: 847-541-7220 • [www.slideproducts.com](http://www.slideproducts.com) • [info@slideproducts.com](mailto:info@slideproducts.com)

## Instructions for Use Item #417 – DuraKote Mold Release

Use this product with a chemical resistant spray bottle such as Slide's Item #42300  
<https://www.slideproducts.com/injection-mold-release-cleaner-accessories/pump-sprayer-bottle-42300/>.

Do not over spray. Hold bottle at least 8 to 12 inches from object to be treated. Using a light even spray will produce best results and give an improved finish.

DuraKote will air dry on the mold surface in approximately 5 minutes. For a harder, more durable and long-lasting film, it may be baked on the mold for 15 minutes at 250°F (121°C) using infrared filters.